



## Wiring diagram for Escon desk unit (with analog telephone)



	FIN 1)	SWE 2)	GB 2)
(A)	<b>ESCON pöytäkoje</b> 0011 1820, 0011 1829 SSTL 7014007, 7014008	<b>ESCON bordsapparat</b> 0011 1810 E 5341009	<b>ESCON Desk Unit</b> 0011 1810
(B)	<b>Ovikoje</b> 0011 0229, 0011 0219, FLPS-941131 SSTL 7061480, 7012365, 7012360	<b>Dörrapparar</b> 0011 0235, 0011 0409 E 5341160, 5341162	<b>Door Unit</b> 0011 0229
(C)	<b>Välikosketin</b> 0011 9222, 0011 9221, 0011 9223 SSTL 7014434, 7014433, 7014435	<b>Televakt</b> 0011 9226, 0011 9224 E 5341011, 5341013	<b>Intermediate Switch</b>
(D)	<b>Modulaarirasia (8-nap)</b> 0019 6581 SSTL 7040218	<b>Modularuttag (8-pol)</b>	<b>Modular Outlet (8-pole)</b>
(E)	<b>Muuntaja (230/24 VAC)</b> MIM-2410 SSTL 7037150	<b>Transformator (230/24 VAC)</b>	<b>Transformer (230/24 VAC)</b>

## Wiring diagram for Escon desk unit (with digital telephone)



	FIN 1)	SWE 2)	GB 2)
(A)	<b>ESCON pöytäkoje</b> 0011 1820, 0011 1829 SSTL 7014007, 7014008	<b>ESCON bordsapparat</b> 0011 1810 E 5341009	<b>ESCON Desk Unit</b> 0011 1810
(B)	<b>Ovikoje</b> 0011 0229, 0011 0219, FLPS-941131 SSTL 7061480, 7012365, 7012360	<b>Dörrapparat</b> 0011 0235, 0011 0409 E 5341160, 5341162	<b>Door Unit</b> 0011 0229
(C)	<b>Modulaarirasia (8-nap)</b> 0019 6581 SSTL 7040218	<b>Modularuttag (8-pol)</b>	<b>Modular Outlet (8-pole)</b>
(D)	<b>Muuntaja (230/24 VAC)</b> MIM-2410 SSTL 7037150	<b>Transformator (230/24 VAC)</b>	<b>Transformer (230/24 VAC)</b>